



Dynamic™

Eyewash Additive Concentrate 8 oz.

- For use with gravity station (FAEWST16)
- Control growth of bacteria in water
- Will stay active up to 120 days
- CONTENTS: Chlorhexidine Gluconate, Propylene Glycol, Purified Water.

Technical Data

Color	Clear
Sizes Available	OS
Packaging	--
Packed	--
Case Dimensions (cm)	--
Case Weight (kg)	0.00
Country of Origin	Canada
Construction	--
Certifications	TAA Compliant
Product Circularity	--

Care Instructions

Directions: Do not use if seal is broken or missing. Do not use in concentrate form. 1- Wear protective eyewear and gloves 2- Follow sanitary procedures 3- Clean eye wash station 4- Rinse with potable water 5- Partially fill station with potable water 6- Add entire content of bottle 7- Fill station to mark 8- Date inspection tag 9- Change solution every 180 days 10- Properly dispose of the empty bottle after use. DO NOT REUSE.